




## [TSN-DA4 Compatibility]

The TSN-DA4 universal camera adapter can be used with cameras that meet the following criteria.

- The tripod mount is to the left of the lens.



- The tripod mount is to the right of the lens.



- For cameras with the tripod mount to the left of the lens (facing the lens).

A: The distance between the center of the tripod mount and the center of the lens.  
 B: The distance between the center of the lens and the base of the camera.  
 C: The distance between the center of the tripod mount and the front of the lens.

- For cameras with the tripod mount to the right of the lens (facing the lens).

D: The distance between the center of the tripod mount and the center of the lens.  
 B and C are the same as above.

A	B	C
0~44mm	21~40mm	~56mm*
D	B	C
0~28mm	21~40mm	~56mm*

\*When the power is ON and the lens is fully extended.



Viewing Position



Photography

- The TSN-DA4 allows a compact digital camera without filter threads to be used for digiscoping.

- Quickly change between photographing and viewing through the scope.

- The camera is attached to the adapter with the camera's tripod mount. Locking mechanisms ensure safe operation.